

# CUT SETTING GUIDE

## CRICUT MAKER (ONLY) ROTARY BLADE



### EXTRA-FINE CREPE PAPER

| SETTING     | PRESSURE |
|-------------|----------|
| CREPE PAPER | MORE     |

### DOUBLE-SIDED CREPE PAPER

| SETTING | PRESSURE       |
|---------|----------------|
| COTTON  | DEFAULT - MORE |

### HEAVY CREPE PAPER

| SETTING | PRESSURE |
|---------|----------|
| DENIM   | DEFAULT  |

### WOOL BLEND FELT

| SETTING           | PRESSURE |
|-------------------|----------|
| FELT, WOOL FABRIC | DEFAULT  |

SELECT ROTARY BLADE

NOTE: These settings may vary for each machine, blade use, and software updates. We recommend you test cut a small area before cutting a full mat of material.

©2026 LIAGRIFFITH.COM • CRICUT DESIGN SPACE V9.72

## CRICUT EXPLORE & MAKER FINE-POINT BLADE



### CARDSTOCK

| CUSTOM SETTING                           | PRESSURE |
|------------------------------------------|----------|
| HEAVY CARDSTOCK                          | MORE     |
| TURN OFF 2X AND INCREASE PRESSURE TO 350 |          |

### LG FROSTED PAPER

| SETTING     | PRESSURE |
|-------------|----------|
| PEARL PAPER | MORE     |

### GOLD PACK PAPER

| SETTING       | PRESSURE |
|---------------|----------|
| MED CARDSTOCK | DEFAULT  |

### VINYL

| HTV              | DECAL         |
|------------------|---------------|
| EVERYDAY IRON-ON | PREMIUM VINYL |
| DEFAULT PRESSURE |               |

### PRINT THEN CUT

| CARDSTOCK        | LABEL PAPER |
|------------------|-------------|
| HEAVY CARDSTOCK  | STICKY NOTE |
| DEFAULT PRESSURE |             |